Product Notes

Warranty

to a major failure

- 1. This product must be installed and used as per these instructions. For indoor ceiling mount applications only.
- 2. This fan is not suitable for use with after-market ducting kits.
- 3. All wiring must be carried out by a licensed electrician.
- 4. Means for disconnection must be incorporated in the fixed wiring in accordance with the Wiring Rules.
- 5. This product should only be cleaned with a damp cloth. Cleaning agents and solvents should not be used.
- 6. Ensure the fan is switched off from the mains supply before removing the grill and diffuser for cleaning purposes.
- 7. This appliance is intended for household use and similar purposes. It is not suitable for use in an environment heavily laden with dust. Under these conditions, the life of the fan motor can be significantly reduced
- 8. The fan is to be installed in a ceiling at least 2.3m above floor level.
- 9. This appliance is not intended for use by young persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- 10. Airflows listed in this product indicate the product performance. Refer to the BCA (Building Code of Australia), or similar, for the appropriate number of room air changes/extraction rate required for a particular installation.

Legrand warrants this product for a period of 5 years from the date

of purchase. These goods come with guarantees that cannot be

You are entitled to a replacement or a refund for a major failure

and for compensation for any other reasonably foreseeable loss


or damage. You are also entitled to have the goods repaired if the

goods fail to be acceptable quality and the failure does not amount

See the Warranty card enclosed with this product for further details.


excluded under the Australian and New Zealand Consumer Laws.

- 11. Ensure the fan is switched OFF from the mains supply before removing fascia for cleaning purposes.
- 12. Ventilation products must have an adequate source of external air to ensure rated performance can be achieved.
- 13. This product contains no serviceable parts and no attempt should be made to repair this product. If the product is faulty it should be discarded
- 14. Severe electromagnetic interference from other products may cause malfunction of this product.
- 15. The material in this product may vary in colour from batch to batch. Colour matching from one batch to another cannot be guaranteed.
- 16. Electrical installations periodically receive transient over-voltages. This product has been designed to minimise the effect of such voltages on connected equipment. It may not give full protection for extreme over voltage transients such as those resulting from a close liahtnina strike.
- 17. Exhaust fans may adversely affect the safe operation of appliances burning gas or other fuels (including those from other rooms) due to back flow of combustion gases. These gases can potentially result in carbon monoxide poisoning. After installation of an exhaust fan such as a partition fan, the operation of flued gas appliance should be tested by a competent person to ensure that back flow of combustion gases does not occur.
- 18. This product utilises intellectual property in the form of registered designs, trademarks, and/or patents. Such intellectual property remains the property of Legrand in all cases.
- 19. Legrand reserves the right to modify the specifications of this product at any time



1 Installation


Current New Zealand Building regulations prohibit the use of non-ducted fans for new installations. If you are replacing an existing fan and a non-ducted fan was originally installed, that was compliant with regulations at the time of installation; it can be replaced with the same type of non-ducted fan. A licensed electrician is required to connect this unit to the mains supply. A lamp (E27 LED 10W Max.) is required for the EFND620WE model (not supplied).




installed. (Do not install within

recess). Be certain that the

by roof beams above a ceiling



1. Determine the position in ceiling 2. Use the template provided where fanlight is required to be to draw a circle 300mm in diameter. To do this insert a 120cm of stove or inside a shower thumb tack in hole at one end and insert a pencil in the other installation area is not restricted hole and scribe a circle. refer table for clearance required



5. Unclip 2 x reflector clips and

■ Fold the toggles in (Fig.6(a)).

■ Unscrew the 3 screws on the

lip of the unit until the gap

inner lip of the unit is greater

than thickness of the Gyprock,

between the toggles and

hinge as in Fig 5.

let the assembly hang by the

- Toggle Clamp open Fig.6 (a Toggle Clamp closed
- 6. Push the unit into the ceiling. Use your fingers to close the toggle clamp (Fig.6(b)).
- Tighten the retention screws clockwise until it is firm and stable allowing the toggles to grip the ceiling material as in Fig.8.
- or other ceiling material. ■ Ensure there is ample clearance in the ceiling space for the draft-stopper to function, see the specification table in section 3.

Customer Service

For all Customer Service and Technical Support please call Monday to Friday during business hours.

Legrand Australia 1300 369 777

Legrand New Zealand

www.hpm.com.au

0800 476 009 www.hpm.co.nz

ABN: 31 000 102 661






Ceiling Exhaust Fan with Light (Non-ducted) Cat. No: EFND620WE (Adaptable Light) EFND620LEDWE (Integrated LED Panel)

Instruction Sheet






3. Use an electric jig saw or small hand saw to cut out around this line. Several holes drilled at a point inside the circle provides a convenient starting point for cutting the panel out.




4. Remove the terminal cover and wire according to the diagrams in section 2.

For EFND620WE only




- 7. Locate clips gently before pressing the assembly in to avoid damage (See fig .7).
- 8. It is recommended that the three toggles are checked for the correct clamping by inspection from above see Fig.8.





- 9. To install E27 LED globe, release the diffuser by holding firmly and rotating anti-clockwise. Insert lamp as shown in Fig.9
- 10. Ensure the diffuser is fixed firmly by locating the latches and turning clockwise.


2 Switching Arrangements



Option 2: Fan and light switched separately








3 Specifications

| | EFND620WE | EFND620LEDWE |
|----------------------------------|---------------------------------------|----------------------------|
| Nominal Input Voltage | 230 - 240 V a.c. 50 Hz | |
| Maximum Power Consumption | 27 W (Max) | 28 W (Max) |
| Class of Protection | Class II | |
| LIGHT | · · | |
| Lampholder | E27 | N/A |
| Consumption | Max.10 W LED Only (Lamp not supplied) | 11 W (Integrated LED Panel |
| Lumen output | N/A | 1190 lm |
| CCT | N/A | 4000k (Cool White) |
| Dimming | N/A | Non-Dimmable |
| FAN | | · |
| Consumption | 17 W (Max) | |
| Airflow | 260 m³/hr, 72 l/sec | |
| Sound pressure level (dBA) at 3m | 46 dBA | |
| Ceiling Cut-out Size | 300 mm | |
| Protrusion from Ceiling | 60 mm | |
| Projection into Ceiling | 230 mm (Max) | |
| Ceiling Depth (Required) | 250 mm (Min) | |
| Impeller Diameter | 210 mm | |
| Fascia size | 330 mm | |
| Weight (Normal) | 2.25 kgs | |

4 Maintenance




5 Box Contents



Cut-out template

EFND620LEDWE (Integrated LED Panel)



1. Ensure the fan is switched OFF from the mains supply before removing

2. This product should only be cleaned with a damp cloth. Cleaning agents and

4. Locate the 3 x latches and turn clock-wise until you hear a click. Ensure all 3

■ Failure to secure the diffuser firmly as outlined above may result in injury.